



42 Edgewood Drive  
Holland, NY 14080  
www.ecostarllc.com

## MAJESTIC NIAGARA SLATE™ ECOSTAR GOLD STAR ROOF SYSTEM

	<u>PAGE</u>
<b>Part 1 – GENERAL</b>	
1.01 Description	2
1.02 Quality Assurance	2
1.03 Submittals	3
1.04 Product Delivery, Storage and Handling	3
1.05 Job Conditions (Cautions and Warnings)	3
1.06 Warranty	3
<b>Part 2 – PRODUCTS</b>	
2.01 General	4
2.02 Tiles	4
2.03 Related Materials	4
<b>Part 3 – EXECUTION</b>	
3.01 Substrate Criteria	5
3.02 Substrate Preparation	5
3.03 Installation	6

©2017 EcoStar LLC. EcoStar, Majestic Slate, Seneca Shake, Seneca Plus, Empire Slate, Empire Shake, Empire Plus, Majestic Niagara Slate, Empire Niagara Slate, Aqua Guard, Glacier Guard and EcoVent are all trademarks of EcoStar LLC.

## PART 1 – GENERAL

### 1.01 DESCRIPTION

- A. Furnish and install Majestic Niagara Slate tile roofing system as specified in the Contract Documents and roof plan.
- B. Furnish and install this Majestic Niagara Slate tile roofing system in strict accordance with specifications and drawings approved by EcoStar.
- C. Related Work
  - 1. Metal flashing work is not covered in this specification since EcoStar does NOT warrant metal flashing. EcoStar advises that metal flashing and securement of metal should be to industry standards (SMACNA) to prevent the metal from pulling free or buckling. EcoStar also suggests that all flashing metal be stainless steel or copper (see 3.03D).
  - 2. EcoStar EcoVent ridge ventilation product will be covered by EcoStar Gold Star Warranty when used on those projects that will be using a ridge ventilation system. If a ridge ventilation system is not to be used on the project, another form of ventilation may be used, but will not be covered by any EcoStar warranties. EcoStar advises that a ridge style venting system be utilized to ensure the best possible air movement and to provide the best aesthetic appearance to the roofing system.

### 1.02 QUALITY ASSURANCE

- A. To qualify for an EcoStar Gold Star Warranty, an authorized EcoStar Gold Star Applicator must install system.
- B. There shall be no deviation made from this specification without written approval from EcoStar prior to the start of the roofing project.
- C. For an EcoStar Gold Star Warranty, upon completion of the installation, an inspection must be conducted by a Field Service Representative of EcoStar to ascertain that the roofing system has been installed according to EcoStar's published specifications and details at time of bid. This inspection is not intended to be a final inspection for the benefit of the owner, but for the benefit of EcoStar to determine whether a warranty shall be issued.
- D. It is the Authorized Gold Star Applicator's responsibility to adhere to all applicable building codes (local and national) and to have or acquire the appropriate licenses and permits for the roofing system installation requirements and limitations in their local areas applicable at the time of the bid.
- E. Specific testing requirements:
  - 1. Class C Fire Resistance – UL 790 Test Standard (ASTM E108)
  - 2. Class 4 Impact Resistance – UL 2218 Test Standard
  - 3. ASTM D3161 – 110 mph Wind Test

©2017 EcoStar LLC. EcoStar, Majestic Slate, Seneca Shake, Seneca Plus, Empire Slate, Empire Shake, Empire Plus, Majestic Niagara Slate, Empire Niagara Slate, Aqua Guard, Glacier Guard and EcoVent are all trademarks of EcoStar LLC.

### 1.03 SUBMITTALS

- A. Submit an "EcoStar Gold Star Pre-Project Survey" to EcoStar's technical department for approval PRIOR to project bid and the job start to enable the technical department to approve and assign a job number to the project.
  - 1. The "EcoStar Gold Star Pre-Project Survey Form" must be filled out completely and accurately to include any prior deviations approved from this specification, including a roof drawing showing all dimensions, all penetrations and roof slope.
- B. When an EcoStar Gold Star Warranty is desired, EcoStar must be contacted PRIOR to project bid and installation. Information will be required for wind speeds greater than 90 mph and deviation from standard slope requirements.

### 1.04 PRODUCT DELIVERY, STORAGE AND HANDLING

- A. Deliver materials in original unopened packages.
- B. Packages shall be labeled with manufacturer's name, brand name and identification of various items.
- C. Majestic Niagara Slate tiles may not be installed if the tiles have been stored in temperatures lower than 45°F. If tiles have been stored in temperatures below 45°F, tiles must be brought back to a material temperature of 45°F. As the temperature rises, Majestic Niagara Slate tiles will expand beyond the designated installation pattern if the product is installed while cold or frozen.
- D. Store all materials in a dry protected area. Damaged materials must **NOT** be used. Installed materials found to be damaged shall be replaced at Gold Star Authorized Applicator's expense.

### 1.05 JOB CONDITIONS (CAUTIONS AND WARNINGS)

- A. Contact the EcoStar technical department for procedures when installing a Majestic Niagara Slate tile roof system during temperatures lower than 45°F.
- B. Do not install the Majestic Niagara Slate tile roof system directly over existing asphalt shingles or existing tile roof systems. All existing roof materials **MUST** be removed prior to installation of the Majestic Niagara Slate tile roof system.
- C. Roofing surface must be free of ice, water, or snow prior to and during the roofing project.
- D. Decking materials must be dimensionally stable prior to installing the Majestic Niagara Slate tiles. If the materials are not dry, EcoStar recommends installing the underlayment and allowing the roof to dry out before installing Majestic Niagara Slate tiles.

### 1.06 WARRANTY

- A. EcoStar will provide the Gold Star Warranty for those materials supplied by EcoStar when an authorized EcoStar Gold Star Applicator completes the project and all required materials have been utilized within the roof system.
- B. Only when an EcoStar Field Service Representative has inspected and approved the completed installation will an EcoStar Gold Star Warranty be issued.
- C. The warranty is available for most types of buildings and structures.

©2017 EcoStar LLC. EcoStar, Majestic Slate, Seneca Shake, Seneca Plus, Empire Slate, Empire Shake, Empire Plus, Majestic Niagara Slate, Empire Niagara Slate, Aqua Guard, Glacier Guard and EcoVent are all trademarks of EcoStar LLC.

- D. The warranty period is expressed on the warranty certificate, which reflects the inclusive dates of coverage.
- E. The warranty does NOT cover the aesthetic appearance of the Majestic Niagara Slate roof installation. It is the responsibility of the EcoStar Authorized Gold Star Applicator to ensure that proper blending of the tiles occurs. When improper blending occurs the aesthetic appearance of the roof can be affected negatively. All materials required for project completion should be on site to blend from. Contact EcoStar Customer Service for available factory-blended options.

**PART 2 – PRODUCTS**

**2.01 GENERAL**

- A. All components of the Majestic Niagara Slate Gold Star roof system are to be products manufactured or supplied by EcoStar LLC.

NOTE: Only products supplied by EcoStar are included in the warranty unless otherwise specified and approved in writing by EcoStar LLC.

**2.02 TILES**

- A. Majestic Niagara Slate tiles are made of Starloy™ an 80% recycled rubber and plastic compound with appropriate colorants and UV stabilizers, At 12” or 14” widths by 22” long, and tapered from ¼” to 5/8” thickness.

Weight shall be determined by the following acceptable tile exposures:

12”	14”
<input type="checkbox"/> 9” = 240 - 260 lbs per square	<input type="checkbox"/> 9” = 260 - 280 lbs per square
<input type="checkbox"/> 10” = 220 - 240 lbs per square	<input type="checkbox"/> 10” = 235 - 255 lbs per square

- B. Majestic Niagara Slate tile color selection shall be made prior to bid opening and shall conform to one or more of the following colors:

<input type="checkbox"/> Black	<input type="checkbox"/> Midnight Grey	<input type="checkbox"/> Federal Grey
<input type="checkbox"/> Smoke	<input type="checkbox"/> Mountain Plum	<input type="checkbox"/> Cedar Brown
<input type="checkbox"/> Chestnut Brown	<input type="checkbox"/> Earth Green	<input type="checkbox"/> Sage Green
<input type="checkbox"/> Stone Red	<input type="checkbox"/> Driftwood	

**2.03 RELATED MATERIALS**

- A. Underlayment

1. AquaGuard – a roofing underlayment recognized for use as an alternative to Type 30 roofing underlayment, consisting of spun bonded polyolefin coated with a layer of U.V. stabilized polyolefin on both sides, meeting requirements of ASTM D2626, referred to as 30 lb and without perforations.
2. Glacier Guard ice & water underlayment – Granular Surface 100 (55-mil), or Smooth Surface High Temperature 300 (40-mil) a composite membrane consisting of fiberglass-reinforced rubberized asphalt laminated to an impermeable polyethylene film layer (Smooth Surface High Temperature) or coated with a granular surface providing maximum skid resistance (Granular Surface).

©2017 EcoStar LLC. EcoStar, Majestic Slate, Seneca Shake, Seneca Plus, Empire Slate, Empire Shake, Empire Plus, Majestic Niagara Slate, Empire Niagara Slate, Aqua Guard, Glacier Guard and EcoVent are all trademarks of EcoStar LLC.

## B. Fasteners

### 1. Aqua Guard

- a. Fasteners shall be corrosive-resistant, plastic-capped roofing nails with a minimum plastic cap diameter of 1". Fasteners shall be 90° to the roof deck and shall not be under or over driven.

### 2. Tile Fasteners

- a. EcoStar ring shank roofing nail with a 3/8" diameter head and a minimum of 1-3/4" long shank made from stainless steel. Nails can be supplied either as a hand-drive style or in coils for use in pneumatic tools. The EcoStar ring shank roofing nail is required for fastening of all EcoStar roof tiles.

## PART 3 - EXECUTION

### 3.01 SUBSTRATE CRITERIA

- A. The building owner or owner's representative is responsible for providing and determining that the substrate is suitable to receive the Majestic Niagara Slate tile roof system and the authorized EcoStar Gold Star Applicator should not proceed until all defects have been corrected.
- B. The Majestic Niagara Slate roof system may only be applied over:
  1. Minimum 1/2" plywood or 7/16" OSB decking, properly gapped for expansion.
  2. Minimum 3/4" tongue and groove wood decking with end gaps not exceeding 1/4", and board widths not exceeding 6 inches.
  3. Approved metal deck systems – (Metal deck systems may require the installation of appropriate thickness nail base insulation prior to attaching the EcoStar tiles). Contact EcoStar's technical department for specifics.
  4. Appropriate clearance on underside of decking or sheathing must be provided for proper penetration of the EcoStar fastener.
- C. Minimum slope of substrate for installation of Majestic Niagara Slate roof systems shall be a minimum of 3/12 for 9" exposure installation and a minimum of 6/12 for 10" exposure installation. Contact the EcoStar technical department for approval of applications on lower slopes or exceptions to this requirement.

### 3.02 SUBSTRATE PREPARATION

- A. The building owner or owner's representative is responsible for ensuring that all wet or damaged substrate has been removed in a re-roofing application.
- B. Existing roof material MUST be removed and a clean substrate free of foreign material be provided prior to the installation of the Majestic Niagara Slate tile roof system. Majestic Niagara Slate tiles may NOT be installed directly over any existing roof material or system.

### 3.03

©2017 EcoStar LLC. EcoStar, Majestic Slate, Seneca Shake, Seneca Plus, Empire Slate, Empire Shake, Empire Plus, Majestic Niagara Slate, Empire Niagara Slate, Aqua Guard, Glacier Guard and EcoVent are all trademarks of EcoStar LLC.

### 3.04 INSTALLATION

- A. Flashing & Sheet Metal – Install sheet metal and flashing metal in all valleys and where required. EcoStar recommends a V-type, W-type, or Double W-type metal valley flashing be used at all valleys.
- B. Where required, install metal edging at all eaves and roof edges.
- C. EcoStar suggests that all metal work be made from copper or stainless steel. Final choice of metal work is at the discretion of the building owner or their designate.
- D. Be aware that staining may occur where runoff from copper metal work comes into contact with the EcoStar tiles. (Example: ridges or cupolas.)

#### E. Underlayment

##### 1. Glacier Guard

- a. Lap end joints 6" and side joints 3.5".
- b. Apply continuous 36" wide sheet in valley centered over valley.
- c. Apply rows of 36" wide sheets along all eaves and rakes. Lap end joints 6" and side joints 3.5".
- d. Apply rows of 36" wide sheets along and around all dormers and roof protrusions. Lap end joints 6" and side joints 3.5".
- e. When applicable install as far up as it can be installed on any head walls or vertical walls a minimum of 12" where possible.
- f. Do not leave Glacier Guard Granular Surface (100) exposed to weather more than 30 days after beginning of installation. Do not leave Glacier Guard Smooth Surface High Temp (300 black) exposed to the weather more than 60 days after the beginning of installation. Do not leave Glacier Guard Smooth Surface High Temp (300 white) exposed to the weather more than 120 days after the beginning of installation.
- g. Installation of Glacier Guard at temperatures below 40°F may require nailing or priming to hold membrane in place while adhesion develops.

##### 2. Aqua Guard

- a. Apply 41.5" wide sheet over complete deck, lapping the area covered with Glacier Guard a minimum of 4".
- b. Refer to the AquaGuard installation instructions found on the label on each roll. Do not leave exposed to weather more than 180 days after beginning of installation.

#### F. Majestic Niagara Slate Tile Installation

- 1. After installing underlayment and before installing the Majestic Niagara Slate tiles, clean the surface of debris and dirt.

©2017 EcoStar LLC. EcoStar, Majestic Slate, Seneca Shake, Seneca Plus, Empire Slate, Empire Shake, Empire Plus, Majestic Niagara Slate, Empire Niagara Slate, Aqua Guard, Glacier Guard and EcoVent are all trademarks of EcoStar LLC.

2. Care must be taken to place tiles so shade variations are evenly distributed over the entire roof area. Shade variations will occur differently from pallet to pallet and within individual pallets. Tiles between bundles and pallets **MUST** be blended to ensure even distribution of shade variations. Shade “mapping” or “blotching” in appearance is not acceptable and the EcoStar Authorized Gold Star Applicator will be required to correct. It is recommended that work not begin until all EcoStar materials have been delivered to the job site so that all the material may be blended together. Periodic ground inspections should be conducted to ensure a random shade pattern to the installation. Please contact EcoStar’s technical department for correct blending procedures. Contact EcoStar Customer Service for available factory-blended options.
3. Minimum Fastening – No less than 2 EcoStar ring shank fasteners per tile shall be used with a minimum length of 1-3/4”. Fasteners should be installed at the designated “nail here” marks on the tile.
4. CAUTION: When using a pneumatic nailer care should be taken to ensure that nails are not over driven. The nail heads should be tight against the tile, but not denting the tile. Tiles with overdriven nails must be removed and re-nailed properly.
5. Do not install tiles against each other. A minimum gap of 3/8” must be maintained between installed tiles. A minimum 3/8” gap must be maintained between installed tiles and any sidewalls or roof protrusion.
6. Beginning at the eave, install a row of Majestic Niagara Slate tiles gapped a minimum of 3/8” between tiles and any protrusions while achieving a 3/4” overhang. Fasten with two EcoStar ring shank fasteners per tile (in location shown on tiles). This layer of tiles will become the starter row. Majestic Slate Traditional tiles can be used for starter row tiles when a lower profile is desired at the eaves. When installing Majestic Slate as the starter row for a 14” wide Majestic Niagara Slate tile roof assembly, care must be taken to make sure that the gaps in the starter row do not line up with the gaps in the first exposed row of tiles. Cut starter tiles to maintain at least 4” of gap offset. The final tile at roof edges or penetrations must be a minimum of 3” wide. This may involve cutting the EcoStar tile to fit. To cut the EcoStar tile to the correct width simply score the front of the tile with a straight edge and utility knife and snap tile at that score. It may be quicker and easier to use a power saw. Any power saw with a blade designed to cut wood can be used to cut the tiles. Install the first course of tiles offset to the starter row. The first course of tiles should be installed flush with the starter row with no exposure.
7. After the initial starter and first row of tiles has been installed, it is recommended that a chalk line be placed parallel to the roof edge running perpendicular to the first row of tiles. This chalk line will ensure that the tiles stay true and plumb to the roof edge throughout installation. Never use red chalk, as this will permanently stain the EcoStar roof tiles.
8. Continue installing tile courses up the roof slope now achieving the correct chosen exposure. It is recommended that chalk lines be placed horizontally up the roof slope for every tile course. This will ensure that each course is installed parallel with the roof eave.
9. Valley Areas – Either an open or closed valley design may be used.
  - a. With an open valley design leave a minimum of 2” on each side of the center of the valley exposed and uncovered by the roof tiles. A V-Style, W-Style, or Double W-Style valley metal may be used.
  - b. With a closed valley design cut the tiles in a straight line to fit no closer than 3/8” against tile of adjoining roof slope.

©2017 EcoStar LLC. EcoStar, Majestic Slate, Seneca Shake, Seneca Plus, Empire Slate, Empire Shake, Empire Plus, Majestic Niagara Slate, Empire Niagara Slate, Aqua Guard, Glacier Guard and EcoVent are all trademarks of EcoStar LLC.

10. Install EcoStar EcoVent ridge vent system per the manufacturer's application instructions and then place the Majestic Niagara Slate Hip/Ridge tile over the ridge vent. A minimum 2 1/2" stainless steel ring shank, hand-driven EcoStar fastener should be used when installing Hip/Ridge tiles to the deck. Place fasteners in the location marked on the tile. Majestic Niagara Slate Hip/Ridge tiles are installed with a maximum 9" exposure.
  11. Install Majestic Niagara Slate – Hip & Ridge tiles at all hip locations using a minimum 2 1/2" stainless steel ring shank, hand-driven EcoStar fastener. EcoStar recommends a chalk line be snapped up the hip line to ensure a straight application up the roof slope. Majestic Niagara Hip & Ridge tiles are installed at a maximum of 9" exposure.
  12. Care must be taken to minimize foot traffic over completed areas of the roof. Majestic Niagara Slate tiles will show mud and dirt causing appearance problems. The removal of dirt and debris is the responsibility of the applicator. Never use chemical cleaning agents not approved by EcoStar to wash an EcoStar roof assembly.
  13. Majestic Niagara Slate tiles can be slippery when wet; caution should be exhibited with early morning dew and after rain. EcoStar strongly recommends the use of toe boards and OSHA approved harnesses and safety equipment at all times.
  14. Upon completion of the roof system installation, inspect and remove all debris from roof.
- G. Phased Roofing – The weathering process of the EcoStar tiles will begin immediately upon installation and exposure to the elements. Therefore, every effort should be made to ensure the EcoStar roof assembly is installed at a continuous rate to completion. Lengthy delays in installation may result in appearance differences when installation is resumed and tiles that have not been exposed to the elements are installed adjacent to tiles that have been on the roof for an extended period of time.